



SERVICE PART LIST FOR #323 NOZZLE

ITEM NO.	DESCRIPTION	PARTS NO.	QUANTITY
1	BAFFLE	A7201	1
2	BUMPER	A7231	1
3	O-RING	O0340	1
4	BALL BEARING(1/8")	F0070	59
5	DISCHARGE TUBE	A7240	1
6	O-RING	O0210	1
7	SPRING	F0141	2
8	PIN	F0290	2
9	NOZZLE TIP	A7251	1
10	SET SCREW	S0090	2
11	BODY ADAPTER	A7219	1
12	BALL BEARING	F0069	2
13	ROUND SPRING	F0022	1
14	SPACER	A7218	1
15	SET SCREW	S0130	2
16	SET SCREW	S0064	1
17	SCREW	S0010	4
18	INDICATING BAND	A0044	1
19	SET SCREW	S0016	2
20	VALVE SEAL PLUG	F0166	1
21	O-RING	O0031	1
22	SCREW	S0018	1
23	ROLL PIN	F0278	1
24	O-RING	O0131	1
25	PLUNGER	F0168	1
26	O-RING	O0125	1
27	O-RING	O0310	1
28	VALVE BODY	A7272	1

29	VALVE LABEL	P0062	1
30	HANDLE	A7221	1
31	O-RING	O0320	1
32	BALL BEARING	F0076	31
33	SCREEN	F0138	1
34	SWIVEL	A0294	1
35	SET SCREW	S0112	1
36	GASKET	D0070	1
37	BALL	F0073	2
38	INSERT	F0208	2
39	SPRING	F0091	2
40	SCREW	S0046	2
41	ACTUATOR	F0137	2
42	SCREW	S0110	2
43	DRIVE SCREW	S0131	4
44	SCREW	S0031	2
45	SET SCREW	S0013	2
46	PISTOL GRIP	A0114	1
47	PISTOL GRIP SCREW	S0044	1